

FIG. 1

095585 092601 103200 98938600




FIG. 2

IN THE CASE OF PLAYING BACK BACKUP-TUNED IMAGES




FIG. 3

0 MOVIE PLAYBACK TIME  $T_m$

0 MUSIC PLAYBACK TIME  $T_s$

FIG. 4




FIG. 5




FIG. 6

T.03260 333360




FIG. 7

SWITCHING OF IMAGES SYNCHRONIZED WITH SUB-SECTIONS OF MUSIC




FIG. 8



SWITCHING OF IMAGES SYNCHRONIZED WITH DISTINCTIVE SOUND




FIG. 9

10/18

"SPIN DOOR"




FIG. 10A

"SLIDE"




FIG. 10B

"BOX"




FIG. 10C




FIG. 11

12/18




FIG. 12




FIG. 13




FIG. 14




FIG. 15

FIG. 16

MENU SELECTION

BACK

CREATE IMAGES WITH MUSIC

PLAYS BACK IMAGES WITH MUSIC

SELECTS THE "CREATE IMAGES WITH MUSIC"

IMAGE/MUSIC SELECTION

BACK

SELECT IMAGES

SELECT MUSIC

SELECTS THE "SELECT MUSIC"

IMAGE SELECTION

BACK

|         |         |       |       |
|---------|---------|-------|-------|
| IMAGE 1 | IMAGE 2 | ...3  | ...4  |
| ...5    | ...6    | ...7  | ...8  |
| ...9    | ...10   | ...11 | ...12 |

TO D



FIG.  
17SELECTS SOME  
UNIT IMAGES

## IMAGE PLAYBACK ORDER SETTING

BACK

PHOTOGRAPHED ORDER

RANDOM

MANUAL

SELECTS THE "PHOTOGRAPHED ORDER"

## IMAGE PLAYBACK TIME SETTING

BACK

5

SEC.

△UP

▽DOWN

GOES TO THE "MUSIC SELECTION"  
OF FIG. 16

## MUSIC SELECTION

BACK

SONG1.WAV

SONG2.WAV

SONG3.WAV

TO G

BACK

 $\sim H$ 

BACK

I

BACK

[illegible]